## **Hinge Adjustments**

Side Adjustment ± 1.5mm (± 1/16") Rotate Screw Clockwise or Counterclockwise

Height Adjustment ± 3.0mm (± 1/8") Loosen Screw, Align Door, Tighten Screw

Depth Adjustment (- 0.7mm, + 1.8mm) (- 1/32", + 1/16") Achivevable Through Cam Adjustment

## **Door Soft Close Deactivation**I= On and O= Off

Door must be closed once for the deactivation to be complete











